

## Operating Instructions

---

### **BRINKMANN Pressure Boosting Pumps**

### **FH11...FH17**



**BRINKMANN PUMPS, Inc.**

47060 Cartier Drive  
Wixom, MI 48393  
USA

Phone: +1 248 926 9400  
Fax.: +1 248 926 9405

Subject to change without prior notice.

[www.brinkmannpumps.com](http://www.brinkmannpumps.com)  
[sales@brinkmannpumps.com](mailto:sales@brinkmannpumps.com)

Order - No.: BA6214 ENGLISH

# Brinkmann Pressure Boosting Pumps series FH11 ... FH17

## Contents

1	Indication to the manual .....	2	8	Servicing and Maintenance .....	8
2	Description of the Product .....	2-5	9	Troubleshooting Guide .....	9
3	Safety instructions .....	6	10	Spare Parts.....	10-11
4	Transportation and Storage.....	6	11	Repair.....	12
5	Installation and Connection .....	7-8	12	Disposal.....	12
6	Start-up / Shut-down .....	8	13	Terms and Conditions .....	13-14
7	Operation.....	8			

## 1 Indication to the manual

This operating manual gives basic instructions which are to be observed during installation, operation and maintenance of the pump. It is therefore imperative that this manual be read by the responsible personnel and operator prior to assembly and commissioning. It is always to be kept available at the installation site.

### 1.1 Identification of safety instructions in the operating manual

Safety instructions given in this manual non-compliance with which would affect **safety** are identified by the following symbol



Safety sign according with ISO 3864 – B.3.1

or where **electrical safety** is involved, with:



Safety sign according with ISO 3864 – B.3.6

Where non-compliance with the safety instructions may cause a risk to the machine and it's function the word

**ATTENTION**

is inserted.

## 2 Description of the Product

### 2.1 General description of the pump

Pumps of this type are multi-stage rotary pumps. Series FH use closed impellers in order to minimizing power consumption and to optimize hydraulic pump efficiencies.

The pump shaft and the motor shaft are connected by a coupling. The pump shaft is sealed by a rotating mechanical seal.

These Pumps are not self-priming.

Pump and motor form a compact and space-saving unit.

The pumps can be mounted next to the coolant tank or the lined-up pump.

### 2.2 Intended use

In combination with pre-pumps or central coolant supply pumps of series FH work as pressure booster up to 26 bar increase within the limiting application in accordance with table 1.


#### Limit of Application (Table 1)

Type	FH11...FH17
Mediums	Industry water, coolant, cooling- and cutting-oils
Kinetic viscosity of the medium	...115 SSU (...25 mm <sup>2</sup> /s)
Temperature of medium	30 ... 175 °F (0 ... 80 °C)
max. inlet pressure	375 PSI (26 bar)
max. operation pressure	775 PSI (54 bar)
Particle-size in the medium	0.04 Inches (1 mm)
min. delivery volume GPM / l/min	FH11 13.2 / 50 FH14 22.2 / 84 FH17 28.8 / 109 at special execution -Q 1% of Q max.
Dry running	The pumps are not suitable for dry running.
Motor cycle time per hour	Motors less 4.0 HP max. 200 from 4.0 HP to 5.4 HP max. 40 from 6.7 HP to 14 HP max. 20 from 15.0 HP and higher max. 15
Ambient temperature	104 °F (40 °C)
Set-up altitude	3280 ft (1000 m)

**ATTENTION**

The pumps are to be operated within their design limits. Applications outside of these limits are not approved. The manufacturer is not responsible for any damages resulting from use of the pumps in such applications.

### 2.3 Type Designation



## 2.4 Technical data

Type	Max. del. pressure spec. weight 1		Max. del. volume		Height		Length		Weight		Power		Noise level <sup>1)</sup> 60 Hz dBA
	PSI	bar	GPM	l/min	H Inches	mm	L Inches	mm	lbs	kg	HP	kW	
FH1102S18	50	3.4	74	275	25.3	643	8.3	212	86.0	39	2.0	1.49	66
FH1103S18	78	5.2	75	285	27.6	702	8.3	212	101.4	46	2.9	2.18	66
FH1104S28	100	6.8	76	290	31.4	798	12.1	308	103.6	47	3.9	2.94	66
FH1105S28	124	8.2	78	300	33.0	837	12.1	308	132.3	60	5.1	3.8	74
FH1106S28	150	10.1	80	310	33.0	837	12.1	308	136.7	62	6.1	4.55	74
FH1107S31	177	11.9	82	320	35.4	899	13.4	340	147.7	67	7.7	5.75	74
FH1108S38	200	13.8	84	325	37.9	963	15.9	404	152.1	69			
FH1109S38	222	15.6	87	330	37.9	963	15.9	404	156.6	71	8.4	6.3	74
FH1110S47	248	17.2	87	330	44.7	1136	19.7	500	225	102	11.5	8.6	77
FH1111S47	276	19.0	88	335					227	103			
FH1112S47	300	20.4	89	340					229	104			
FH1113S50	322	22.1	89	340	46.0	1168	20.9	532	247	112	13.8	10.3	77
FH1114S57	342	23.8	90	350	48.5	1232	23.5	596	249	113			
FH1115S57	362	25.0	90	350					251	114			

1) Noise emissions measured in accordance with  
DIN 45635 at a distance of 39.37 Inches (1 m)  
The motor is surface-cooled and compliant with  
DIN IEC 34 and EN 60034 (protection degree IP 55).

Type	Max. del. pressure		Max. del. volume		Height		Length		Weight		Power		Noise level <sup>1)</sup> 60 Hz dBA
	spec. weight 1 PSI	bar	GPM	<i>l/min</i>	H Inches	<i>mm</i>	I Inches	<i>mm</i>	lbs	<i>kg</i>	HP	<i>kW</i>	
FH1402S18	60	4.0	124	460	27.6	702	8.3	212	105.8	48	3.9	2.94	66
FH1403S28	92	6.0	125	475	33.0	837	12.1	308	136.7	62	6.1	4.55	74
FH1404S28	120	8.1	128	490	34.1	867	12.1	308	149.9	68	8.4	6.3	74
FH1405S38	156	10.2	130	500	40.9	1040	15.9	404	216	98	11.5	8.6	77
FH1406S38	182	12.2	132	510					218	99			
FH1407S47	218	14.4	135	520	44.7	1136	19.7	500	240	109	13.8	10.3	77
FH1408S47	242	16.4	138	530	45.0	1144	19.7	500	280	127	16.9	12.6	79
FH1409S57	277	18.6	142	545	48.8	1240	23.5	596	289	131	20.1	15.0	79
FH1410S57	300	20.8	143	550					293	133			
FH1411S66	330	22.8	146	560	67.0	1701	27.2	692	355	161	25	18.5	81
FH1412S66	360	25.0	148	570					362	164			

1) Noise emissions measured in accordance with  
DIN 45635 at a distance of 1 m

The motor is surface-cooled and compliant with  
DIN IEC 34 and EN 60034 (protection degree IP 55).

Type	Max. del. pressure		Max. del. volume		Height		Length		Weight		Power		Noise level <sup>1)</sup> 60 Hz dBA
	spec. PSI	weight 1 bar	GPM	<i>l/min</i>	<b>H</b> Inches	<i>mm</i>	<b>L</b> Inches	<i>mm</i>	lbs	<i>kg</i>	HP	<i>kW</i>	
FH1702S18	60	4.1	142	550	29.2	741	8.3	212	132.3	60	5.1	3.8	72
FH1703S28	94	6.4	148	555	34.1	867	12.1	308	145.5	66	7.7	5.75	74
FH1704S28	124	8.4	150	570	37.1	943	12.1	308	201	91	11.5	8.6	77
FH1705S38	158	10.8	153	580	40.9	1040	15.9	404	254	115	13.8	10.3	77
FH1706S38	190	13.1	158	600	41.3	1048	15.9	404	260	118	16.9	12.6	79
FH1707S47	220	15.2	160	605	45.0	1144	19.7	500	278	126	20.1	15.0	79
FH1708S47	252	17.4	162	610					282	128			
FH1709S57	283	19.7	165	620	63.2	1605	23.5	596	340	154	25	18.5	81
FH1710S57	312	21.8	167	630	64.1	1629	23.5	596	381	173	30	22.0	84
FH1711S66	346	24.0	170	640	67.9	1725	27.2	692	386	175			

1) Noise emissions measured in accordance with  
DIN 45635 at a distance of 1 m

The motor is surface-cooled and compliant with  
DIN IEC 34 and EN 60034 (protection degree IP 55).

### 3 Safety instructions

When operating the pump, the safety instructions contained in this manual, the relevant national accident prevention regulations and any other service and safety instructions issued by the plant operator are to be observed.

#### 3.1 Hazards in the event of non-compliance with the safety instructions

Non-compliance with the safety instructions may produce a risk to the personnel as well as to the environment and the machine and results in a loss of any right to claim damages.

For example, non-compliance may involve the following hazards:

- Failure of important functions of the machines/plant
- Failure of specified procedures of maintenance and repair
- Exposure of people to electrical, mechanical and chemical hazards
- Endangering the environment due to hazardous substances being released

#### 3.2 Unauthorized modes of operation



- Pump may not be used in potentially explosive environments!
- Pump and discharge piping are not designed to hold any weight and may not be used as a step ladder.

#### 3.3 Remaining Risk



##### Risk of Injury!

Risk of squeezing or crushing body parts when installing or removing the pump exists. Proper and secured lifting tools must be used.

##### Risk of burns!

The pump must have cooled down sufficiently prior to commencing any repair, maintenance or installation.

#### 3.4 Qualification and training of operating personnel

The personnel responsible for operation, maintenance, inspection and assembly must be adequately qualified. Scope of responsibility and supervision of the personnel must be exactly defined by the plant operator. If the staff does not have the necessary knowledge, they must be trained and instructed, which may be performed by the machine manufacturer or supplier on behalf of the plant operator. Moreover, the plant operator is to make sure that the contents of the operating manual are fully understood by the personnel.

#### 3.5 Safety instructions relevant for operation

- If hot or cold machine components involve hazards, they must be guarded against accidental contact.
- Guards for moving parts (e.g. coupling) must not be removed from the machine while in operation.
- Any leakage of hazardous (e.g. explosive, toxic, hot) fluids (e.g. from the shaft seal) must be drained away so as to prevent any risk to persons or the environment. Statutory regulations are to be complied with.
- Hazards resulting from electricity are to be prevented (see for example, the VDE Specifications and the bye-laws of the local power supply utilities).
- The pumps are only secured safely if properly attached to the floor and to the lined-up pump or tank.
- The female threads on the motor **MUST NOT** be used to lift the entire pump and motor assembly.

#### 3.6 Safety instructions relevant for maintenance, inspection and assembly work

Any work on the machine shall only be performed when it is at a standstill, it being imperative that the procedure for shutting down the machine described in this manual be followed.

Pumps and pump units which convey hazardous media must be decontaminated.

On completion of work all safety and protective facilities must be re-installed and made operative again. Prior to restarting the machine, the instructions listed under "Start up" are to be observed.

#### 3.7 Signs on the pump

It is imperative that signs affixed to the machine, e.g.:

- arrow indicating the direction of rotation
  - symbols indicating fluid connections
- be observed and kept legible.

#### 3.8 Unauthorized alterations and production of spare parts

Any modification may be made to the machine only after consultation with the manufacturer. Using spare parts and accessories authorized by the manufacturer is in the interest of safety. Use of other parts may exempt the manufacturer from any liability.

### 4 Transportation and Storage

Protect the pump against damage when transporting. The pumps may only be transported in a horizontal position and hooks or straps must be attached on the motor and pump end.

Do not use the pump shaft for connecting any transportation aids such as hooks or straps.

Pumps must be drained prior to their storage.

Store pump in dry and protected areas and protect it against penetration of foreign bodies.

Always store pump above the freezing point!

## 5 Installation and Connection

### 5.1 Mechanical installation

During any assembly or disassembly process the pumps must be secured against tipping through ropes for example at all times.


Pumps must be mounted securely. Piping, tank and pumps must be mounted without any tension.

The liquid entrance is situated at the pump body. The pressure connection is at the connection cover in the end of the pump unit (They are marked with arrows).

Possible leakage will be caught by a leakage chamber and returned to the tank by means of a leakage line from the leakage bore on the upper side of the flange.

To obtain the full flow rate it is recommended to choose for the pipework the nominal bore diameter of the pumps cross section for connection. Therefore pipe bends should be used, not pipe angles!

The pipework must be qualified for occurring hydraulic pressure.



Dimensions in Inches / mm

\*) Dim. for 8.6 HP to 13.8 HP , \*\*) Dim. for 17 HP, \*\*\*) Dim. up 23 HP

### ATTENTION

**Pay attention of the max. tightening torque for piping connection**

Type	Pipe connection	Cast iron
FH11...17	G 1 ½	110 ft. Lbs (150 Nm)

**When installed the space around the pump must be large enough to provide sufficient cooling of the motor.**

**The suction port cannot support the weight of the supply pipe.**

### 5.2 Electric wiring



**All service work must be carried out by qualified service personnel. Pump must be disconnected from the power source and all rotating parts must stand still. Reassure that pump is disconnected from power source and cannot be switched on. Verify that there is no voltage at the terminal board!**

According to the European Standard EN809 a motor overload must be installed and properly set to the full load amps stated on the pump name plate.

It is the responsibility of the machine operator to decide whether or not an additional emergency switch must be installed.



**Danger!**

#### Risk of electric shock

Our asynchronous motors can optionally be fitted with temperature sensors in the form of triplet PTC thermistors, which are used for thermal monitoring of the motor windings. Please note that the temperature sensors meet the insulation requirements of basic insulation. The improper connection of the triplet PTC thermistors to evaluation units that do not have a protective function against overvoltage in the event of a fault can lead to voltages dangerous to the touch and electric shock.

Please check whether the evaluation units you intend to use are permissible for the electrical connection of the temperature sensors.

#### 5.2.1 Circuit





Tension voltage and frequency must correspond with the shown specification on the nameplate.

The pump must be wired so that a solid longterm electrical connection is ensured. Establish a solid ground connection.

**The electrical wiring must be performed according to the wiring diagram shown inside the terminal box cover. (Please see above sample wiring diagrams)**


**Wiring diagram e.g.**

**Up to 13.4 HP**  
**Voltage changing 1:2 YY / Y**  
 e.g. 230 / 460 V, 60 Hz




**Circuit on request**

**Y (Star connection)**  
 up to 7.4 HP  
 (5.5 kW)



Y 440 V – 480 V  
 60 Hz

**Δ (Delta connection)**  
 8, 8.7, 10.1, 12.1, 14.7, 17.4 HP  
 (6, 6.5, 7.5, 9, 11, 13 kW)




Δ 440 V – 480 V  
 60 Hz

**Voltage changing Δ / Y.**


e. g. 220 V – 240 V / 380 V – 420 V, 50 Hz

Δ (Delta Connection)

Y (Star Connection)



Δ 220 V – 240 V,  
 50 Hz



Y 380 V – 420 V,  
 50 Hz

There may be no foreign objects such as dirt, particles or humidity inside the terminal board.

Mount terminal board cover to motor tight against dust and humidity and close up all unused wiring ports.

**ATTENTION**

When Variable Frequency Drives are used interfering signals might occur.

Non-sinus shaped supply voltage from a variable frequency drive might result in elevated motor temperatures.

**6 Start-up / Shut-down**

**6.1 Start-up**

**ATTENTION**

Switch off at the mains.

After connection the electrical wires, close the terminal box. Briefly start the motor (max. 30 sec.) and check

the rotation according to the arrow on the top of the motor.

If the direction is incorrect change over two of the power leads.

**6.2 Shut-down**

All service work must be carried out by qualified service personnel. Pump must be disconnected from the power source and all rotating parts must stand still. Reassure that pump is disconnected from power source and cannot be switched on. Verify that there is no voltage at the terminal board!

Open terminal box and disconnect the power leads. Empty out the pump.

**7 Operation**


**Liquid level**

The valve on the suction side of the pump must be opened 1 or 2 seconds before starting up the pump to avoid the damage resulting from low pressure.

Do not switch on pressure boosting pump FH before positive inlet pressure by a primary pump or by a static head pressure (from a central filtration system) is established. Max. inlet pressure 375 PSI (26 bar).

CAUTION: avoid hydraulic shocks!

Care has to be taken that the pump station will not run empty.



If the pump should lock up and cease, shut pump down (see 6.2) and disconnect from power supply. Pump must be uninstalled and removed from the system prior to its repair.





**Attention! Potential Risk of Burning!**

**Surface temperatures above 50°C do occur during regular operation, i.e. on the surfaces of the motor and bearing housing.**

**It must be insured that the pump has cooled down sufficiently prior to performing any repair or maintenance work.**

**8 Servicing and Maintenance**

**ATTENTION**


The surface of the motor must be kept free of dirt. The motor shaft is spinning in permanently greased ball bearings (with special grease and increased bearing play) and does not require any special maintenance.

**9 Troubleshooting Guide**

<b>Fault</b>	<b>Cause</b>	<b>Remedy</b>
Motor does not start, no motor noise	At least two of the power supply leads have failed	Check fuses, terminals and supply leads .
	Overload has tripped	Inspect overload
Motor does not start, humming noise	One of the supply leads has failed	See above
	Impeller faulty Motor bearing faulty	Replace impeller Replace bearing
Overload trips	Pump locked up mechanically	Inspect pump hydraulics
	High on/of cycling frequency	Check application
Power consumption is too high	Wrong direction of rotation of impeller	See above
	Lime or other deposits mechanical friction	Clean pump mechanism repair pump
Motor overheats	High on/off cycling frequency	See above
	Wrong power supply (voltage or cycles)	Power supply must correspond with name plate rating
Pump does not pump	Insufficient cooling	Check air flow at motor fan
	Pre-pump does not work Pump mechanism faulty Pipe blocked	Check the pre-pump replace pump mechanism Clean pipe
Insufficient flow and pressure	Wrong direction of rotation of impeller	Change over two power supply leads
	Pump mechanism silted up Worn pump mechanism	Clean pump mechanism Replace pump mechanism
Incorrect flow or pressure	Wrong power supply (voltage or cycles)	Power supply must correspond with name plate rating
Running noise/Vibration	Foreign objects in pump end	Remove foreign objects
	Impeller damaged	Replace impeller
	Bearing/Bushing broken	Replace bearing/bushing

## 9 Spare Parts

### 9.1 Spare part list for Pressure Boosting Pumps Series FH11, FH1402S18...FH1408S47




### FH1702S18...FH1706S38

Item	Description	
1	Stator with terminal board	
2	Motor flange	
3	End shield	
4	Motor shaft with rotor	
5	Terminal box up to 8.4 HP	
6	Terminal box frame from 11.5 HP and over	
7	Terminal box cover from 11.5 HP and over	
8	Fan	
9	Fan cover	
10	Gasket	
11	Gasket from 11.5 HP and over	
13	Retaining ring	
13	Retaining ring 2.0...3.9 HP	DIN 471
14	Thread rolling screw	DIN 7500
15	Ball bearing	DIN 625
15	Ball bearing 2.0...3.9 ; 11.5 HP	DIN 628
16	Ball bearing	DIN 625
17	Slotted cheese head screw	DIN 84
18	Hexagon socket head cap screw	DIN 912
19	Parallel pin	DIN 7
20	Retaining ring up to 7.5 HP	DIN 472
21	Retaining ring up to 7.5 HP	DIN 471
22	Socket head cap screw	DIN 912
23	Bearing cover 11.5 HP and over	
24	Socket head cap screw 11.5 HP and over	DIN 931
25	Shaft nut 11.5 HP and over	
26	Compensation disk	
27	O-ring from	
28	Shaft seal	
29	Rotary shaft seal	
30	Nut 15 HP and over	DIN 934
50	Pump body	
51	Connection cover	
52	Pump shaft	
53	Diffusor with sliding ring	
54	Entering stage with sliding ring	
55	Outflow stage	
56	Bearing stage with sliding ring	
57	Impeller	
58	Spacer-long 2 x per stage	
59	Spacer-short 1 x per bearing stage	
60	Sliding ring	
61	Shaft sleeve	
62	Supporting ring	
63	Spiral backup ring	
64	Mech. Seal stop ring cover	
65	Mech. seal stop half-ring	
66	Mech. seal washer	
67	Pump casing	
69	Clamp coupling	
70	Coupling shield with M5 screw	
71	Stud bolt	
72	O-ring	
73	Rotary shaft seal	
74	Mechanical seal	
75	Retaining ring	
76	Parallel pin	DIN 7
77	Hexagon head cap screw	DIN 933
78	Hexagon socket head cap screw	DIN 912
79	Serrated lock washer	DIN 6798

80	Hexagon nut	DIN 934
81	Hexagon cap nuts	DIN 917
82	Woodruff key	DIN 6888
83	Distance plate instead of impeller / 60 HZ	
84	Hexagon socket pipe plug	DIN 906

**9.2 Spare part list for the pressure boosting pumps series**  
**FH1409S57...FH1412S66**

**FH1707S47...FH1711S66**



**Item Description**

- |    |                                    |          |
|----|------------------------------------|----------|
| 1  | Motor                              |          |
| 2  | Bearing housing                    |          |
| 3  | Bearing shaft                      |          |
| 4  | Woodruff key                       | DIN 6888 |
| 5  | Ball bearing                       | DIN 628  |
| 6  | Distance plate                     |          |
| 7  | Ball bearing                       | DIN 628  |
| 8  | Coupling                           |          |
| 9  | Socket head cap screw              | DIN 912  |
| 10 | Threaded pin                       | DIN 705  |
| 11 | Bearing cover                      |          |
| 12 | Socket head cap screw              | DIN 912  |
| 13 | Nilos-ring                         |          |
| 16 | Nilos-ring                         |          |
| 21 | Shaft nut                          |          |
| 22 | Socket head cap screw              | DIN 912  |
| 50 | Pump body                          |          |
| 51 | Connection cover                   |          |
| 52 | Pump shaft                         |          |
| 53 | Diffusor with sliding ring         |          |
| 54 | Entering stage with sliding ring   |          |
| 55 | Outflow stage                      |          |
| 56 | Bearing stage with sliding ring    |          |
| 57 | Impeller                           |          |
| 58 | Spacer-long 2 x per stage          |          |
| 59 | Spacer-short 1 x per bearing stage |          |
| 60 | Sliding ring                       |          |
| 61 | Shaft sleeve                       |          |
| 62 | Supporting ring                    |          |
| 63 | Spiral backup ring                 |          |
| 64 | Mech. seal stop ring cover         |          |
| 65 | Mech. seal stop half-ring          |          |
| 66 | Mech. seal washer                  |          |
| 67 | Pump casing                        |          |
| 69 | Clamp coupling                     |          |
| 70 | Coupling shield with M5 screw      |          |
| 71 | Stud bolt                          |          |
| 72 | O-ring                             |          |
| 73 | Rotary shaft seal                  |          |
| 74 | Mechanical seal                    |          |
| 75 | Retaining ring                     |          |
| 76 | Parallel pin                       | DIN 7    |
| 77 | Hexagon head cap screw             | DIN 933  |
| 78 | Hexagon socket head cap screw      | DIN 912  |
| 79 | Serrated lock washer               |          |
| 80 | Hexagon nut                        | DIN 934  |
| 81 | Hexagon cap nuts                   | DIN 917  |
| 82 | Woodruff key                       | DIN 6888 |
| 83 | Distance plate                     |          |
|    | instead of impeller / 60 Hz        |          |
| 84 | Hexagon socket pipe plug           | DIN 906  |

### 9.3 Indications to the spare part order

Spare parts are available from the supplier. Standard commercially available parts are to be purchased in accordance with the model type. The ordering of spare parts should contain the following details:

#### 1. Pumptype

e.g. FH1407S47

#### 2. Pump No.

e.g. 08246214

The date of the construction year is a component of the pumps type number.

#### 3. Voltage, Frequency and Power

Take item 1, 2 and 3 from the nameplate

#### 4. Spare part with item No.

e.g. Impeller item No. 57

## 10 Repair

### 10.1 Exchange the rotary mechanical seal: FH11...FH17

- 1) Disconnect the pump from the power supply.
- 2) Loosen the M5 screws and pull out coupling shield (70). Remove clamp coupling (69.1, 69.2) and parallel pin (76).
- 3) Loosen and pull off the hexagon cap nuts (81), the stud bolt (71), connection cover (51) and the pump casing (67) from the pump unit. Remove pump unit with pump shaft (52) from the pump body (50).
- 4) Take off rotating axial face seal unit (74.1-74.5) and mech. seal washer (66) from the shaft (52) and clean the shaft. Pay attention to the drilled hole for the parallel pin (76) that it is without any bur. Check the sliding surface for the rotary shaft seal (73) for any damage.
- 5) Remove complete seal (74.6, 74.7) from the pump body (50) and clean the seat.
- 6) Mounting of the new axial face seal :  
Ensure that the sliding surfaces of the ring and the rotating axial face seal unit are free from grease and dirt.  
Moisten the angle-sleeve (74.7) of the counter ring lightly with rinse water / (water with washing-up liquid) and push the unit into the seat of the pump body (50).  
Slide the mech. seal washer (66) first and then the axial face seal (74.1-74.5) onto the pump shaft (52).
- 7) Lubricate lightly the lip of the rotary shaft seal (73) and push it into the pump body (50). Then insert the pump shaft (52) with the pump unit through the rotary shaft seal (73).
- 8) Fit together the coupling clamp (69) with the parallel pin (76) around the shafts, tighten the hexagon socket head cap screws (78) with the serrated lock washer (79) lightly.  
Be sure that the key of the motor shaft (4) coin-

cides with the key groove of the coupling clamp (69.1). Press the pump shaft (52) toward the motor and tighten the screws.

The distance between the two shaft ends **must be zero**.

#### 9) Lubricate the O-ring seal (72)

Put on the spiral-backup ring (63), the O-ring seal (72), the connection cover (51) and the pump casing (67) and screw evenly the stud bolt (71) and the hexagon cap nuts (81).

During the assembly from (63) and (72) take care of the order. See the pump drawing.

#### 10) Fit the coupling shield (70) into the pump body (50) and tighten the M5 screws.


#### 11) Reconnect pump to the power supply.

Note torques for the screw connections!

When putting the pump back into use, **make sure the direction of rotation is correct!**

### Tightening torques for screwed connections

Thread - Ø	M4	M5	M6	M8	M10
Strength classes	4.8	4.8	8.8	8.8	8.8 / 10.0
Tightening torque ft. lbs. (Nm)	<b>0.7</b> <b>(1)</b>	<b>2.2</b> <b>(3)</b>	<b>3.3 (4.5)</b> <b>15 (20)</b> Clamp coupling	<b>11 (15)</b> <b>22 (30)</b> Clamp coupling	<b>22 (30)</b>



## 11 Disposal

When disposing of the pump or the packaging materials the local and national regulation for proper disposal must be complied with.

Prior to its disposal, the pump must be completely drained and decontaminated if necessary.

## 12 Brinkmann Pumps Inc. Terms and Conditions

The following terms and conditions govern all quotations made by Brinkmann Pumps Inc. („Brinkmann“) and any orders based upon these quotations. No contract term or condition shall be amended, deleted or added without the express written consent of Brinkmann, and Brinkmann hereby rejects any terms set forth in any other writing which are in addition to or different from the terms in this quotation.

These items and conditions and any other terms and conditions delivered in writing by an authorized agent of Brinkmann contemporaneously herewith constitute the complete agreement between Brinkmann and the buyer and supersede all prior oral, written or printed statements of any kind (including any terms and conditions submitted by the buyer and performance or production data from any source whatsoever, including references to accuracy, capacity, and capability of products, all of which are estimates only) made by Brinkmann or the buyer or their respective representatives. No statement, recommendation or assistance given by Brinkmann or its representatives to buyer or its representatives, in connection with the use of any products by buyer, shall constitute a waiver by Brinkmann of any of the provisions hereof or affect Brinkmann's liability, as defined herein. All transactions covered hereby and all terms and conditions of sale shall be governed by the laws of the state of Michigan.

### Prices

The products offered in this proposal and the prices quoted are based on our understanding of buyer's requirements; any change in requirements will necessitate a revision in prices quoted. Prices are F.O.B. our dock, Wixom, Michigan, or other location as specified on proposal. Brinkmann's prices do not include sales, use, excise, or similar tax, applicable to the sale or use of the equipment proposed. These taxes shall be paid by the buyer, or in lieu thereof, the buyer shall provide Brinkmann with a tax exemption certificate acceptable to the taxing authorities.

### Delays or failure to deliver

Brinkmann shall not be responsible for delay or failure to deliver due to acts of God, or to government action (civil or military), or to prior orders, or to fire, embargo, strike or other labor problems, wrecks, delays in transportation, unusually severe weather or inability to obtain necessary labor or materials from the usual source of supply, or any other circumstances beyond Brinkmann's control.

Brinkmann shall have the right to furnish suitable substitutes for materials which cannot be obtained because of such force majeure.

### Installation

Buyer shall install at its own expense, all products covered hereby in accordance with the operating instructions to be furnished to buyer upon request. Unless otherwise stated, no installation services are included in the price indicated.

### Limited warranty

Brinkmann warrants to the buyer (but not to any others) for a period of one year from date of shipment that all new parts are free from defects in material and workmanship. Brinkmann's said warranty shall exist only if buyer gives written notice to Brinkmann within ten days after the first determination that the part is defective and within the aforesaid one year period from the date of shipment and includes in said notice consent to Brinkmann to inspect, at any reasonable time, said part and the machine in which it may be embodied, and if, and only if, Brinkmann determines to its reasonable satisfaction upon said inspection that said part and the machine in which it may be embodied are, and have been, used in accordance with all Brinkmann's instructions as to maintenance and operation set forth in the operating instructions relating to the machine. Brinkmann's warranty is limited to shipping to buyer replacement of any part which is so proven to be defective and in any event shall have **no liability whatsoever for incidental or consequential damage or loss of profit**, including damages resulting from personal injury or death, or damage to, or loss of use of, any property. Brinkmann is not responsible for shipping costs or labor, extends no warranty of any kind for gasket, seals and wear and tear materials. Notwithstanding any provisions of these terms and conditions, **this warranty is the only warranty extended by Brinkmann in connection with any sales of products and is in lieu of all other warranties, express or implied, including warranties of merchantability or fitness for purpose.** No agent, employee or representative of Brinkmann has any authority to bind Brinkmann to any affirmation, representation, or warranty concerning the products that are the subject of this quotation beyond that specifically included in the written quotation. Brinkmann shall have no obligation to install or provide improvements or changes in design adapted by Brinkmann for similar equipment subsequent to acceptance of buyer's order.

**Warranties have been discussed and understood by both parties.**

### Buyer's use and O.S.H.A.

Buyer shall use and require all persons operating the equipment to use all proper and safe operating procedures set forth in operating instructions relating to the equipment and observe all occupational safety health and standards act (O.S.H.A.), American National Standard Institute (ANSI), and state regulations as required and all available, feasible and practical point of operation safety devices consistent with buyer's use of the equipment. Buyer shall not remove or modify, any device, warning sign, operating instructions or work handling tools installed on or attached to the equipment. Buyer shall notify Brinkmann promptly, in writing, and in all events within ten (10) days after its occurrence, of any accident or malfunction involving any equipment which results in injury to or death of persons or damage to property, or the loss of use thereof and buyer shall cooperate fully with Brinkmann in investigation and determining the cause of any such occurrence of malfunction. At Brinkmann's request made at any time, buyer will either at its or Brinkmann's place of business, permit to redesign, remodel or revise the equipment and buyer waives any claims against Brinkmann for buyer's inability to use the equipment during the time that same is out of service for such revision, modification or redesign.

Brinkmann shall not be responsible for any failure to comply which results from the location, operation, design, use or maintenance of the equipment from alternation of the equipment by persons or firms other than Brinkmann, or from an option or accessory to the equipment by persons or firms other than Brinkmann, which was available to the buyer but omitted at the buyer's direction, or from design or instructions furnished by the buyer or its agents. In view of the above, Brinkmann does not make any warranties with respect to O.S.H.A. requirements, including noise; and will not be responsible for fines, penalties, or consequential damages.

### Payment terms

Net payment in full of all invoices is due thirty (30) days net, unless stated otherwise in quotation. Any unpaid balance thereafter shall be subject to a service charge of 1.75 % per month or, if illegal, at the highest rate allowed by law. There shall be no extension or change in the time for payment due to delay in installation and/or delays in operation of the equipment caused by damage, warranty service or warranty replace-

ment of parts. If after Brinkmann's acceptance of buyer's purchase order, buyer requests Brinkmann to delay shipment of the equipment, the purchase price shall become due and owing thirty (30) days after the equipment is ready for shipment.

If buyer fails to pay the purchase price as provided herein and Brinkmann institutes a lawsuit for the collection of said price, buyer agrees to pay Brinkmann's reasonable attorney fees incurred in connection therewith.

#### **Acceptance of orders**

Quotations are offered for written acceptance within thirty (30) days from date (unless otherwise stated) but are subject to change without notice at any time before acceptance. If any order contains printed, stamped or other provisions inconsistent or in conflict with the terms and conditions hereof, the terms and conditions hereof shall control, unless otherwise specifically stated by Brinkmann in writing. All clerical errors are subject to correction in favor of either party upon notice of either party. All orders are subject to the credit approval of Brinkmann. An order containing subject matter not within the contemplation of the proposal shall be subject to a further quotation as to price or delivery or both. Modifications, changes, deferred shipments, cancellations or additions will be effective only if accepted by Brinkmann in writing and then only upon terms that will indemnify Brinkmann against all costs and losses.

#### **Title and security agreement**

Delivery to carrier shall constitute transfer to the buyer, and all risk of loss or damage in transit shall be borne by the buyer.

By execution of a purchase order, buyer hereby grants to Brinkmann a security interest in the equipment covered by the proposal, and its products and/or proceeds in order to secure the payment of the purchase price thereof and buyer authorizes to file financing statements reflecting this security interest without buyer's signature. Buyer will cooperate with Brinkmann in preparing documents necessary to perfect this security interest.

#### **Proprietary and other materials**

This quotation and all drawings, specifications, materials, patterns, and special purpose manufacturing aids which are supplied to buyer by Brinkmann shall be kept in confidence and shall be listed and maintained in suitable condition at the expense of buyer and are to be considered the property of Brinkmann held on consignment by buyer and to be insured while in buyer's possession. Such articles and all copies thereof from any source shall be returned to Brink-

mann at any time upon request and shall not be used for or by any third parties without the express written permission of Brinkmann.

#### **Performance in event of default**

In addition to the rights and remedies conferred upon Brinkmann by law, Brinkmann will not be required to proceed with the performance of any order or contract if buyer is in default in the performance of any order or contract with Brinkmann and in case of doubt as to buyer's financial condition, shipments under an order may be suspended or sent sight draft with bill of lading attached and Brinkmann may decline further shipments except for cash before shipment.

#### **Hold harmless/indemnity**

Except to the extent of the limited warranty set forth above and Brinkmann's own gross negligence or willful misconduct, buyer hereby:

- (1) waives, releases and discharges any and all claims of any and every kind (including but not limited to injury or death of any person or damage to property), which it may have at any time against Brinkmann, its agents or employees, by reason of or arising out of any claimed improper design, specification or manufacture of the equipment sold hereunder, or of any claimed inadequate or insufficient safeguards or safety devices; and (2) covenants to indemnify and hold harmless Brinkmann, its agents and employees of, from and against any and all loss, damage, expense (including attorney's fees), claims, suits or liability which Brinkmann or any of its employees may sustain or incur at any time for or by reason of any injury or death of any person or persons or damage to any property, arising out of any claimed improper design or manufacture of the equipment sold hereunder, or of any claimed inadequate or insufficient safeguards or safety devices.

#### **Electrical equipment**

Motors, electrical equipment and wiring on the equipment quoted will be supplied in accordance with the manufacturer's standards. Unless specifically quoted they are not guaranteed to meet ordinances of any local governing body and the responsibility of conforming to any local ordinance is assumed by the buyer.

#### **Inspection and testing, production estimates and performance**

All working drawings or other materials provided by Brinkmann are for general information purposes only and may or may not relate to buyer's order or other equipment. Any specifications contained therein are not binding on Brinkmann except as expressly so stated. Brinkmann reserves the right to make, at any time, such changes in detail of design or construction as shall in the sole judg-

ment of Brinkmann constitute an improvement over former practice. Production data, where given, are based on Brinkmann's careful analysis and understanding of the limits of accuracy, machinability of materials, amount of material to be removed, handling facilities provided, and location points but are nonetheless an estimate only and not guaranteed or warranted. In no event shall Brinkmann be responsible for performance figures supplied by other parties. If by written agreement the equipment is to be subject to acceptance tests before shipment, rejection under this clause must take place prior to shipment.

#### **Returned equipment**

In no case is equipment to be returned without first obtaining written permission from Brinkmann. Unless otherwise expressly agreed an order for equivalent value must accompany returned equipment and all such returned equipment will be accepted for credit only after inspection. Equipment returned without good cause and for which no credit is given shall be subject to a restocking charge. Buyer returning equipment must pay transportation charges and bear risks of loss or damage to goods while in transit. Acceptance of returned products by Brinkmann's receiving department shall not bind Brinkmann nor have any force or effect unless acceptance is made by Brinkmann in writing.